## How to make moves with your Smart Switch:

Schedule your motion sensor to sleep when you sleep.

response schedule under

room motion sensor.

Automate your lights by enabling ambient light and motion detection.

Go to **CYNC app** and enable the ambient light sensor under **room motion** sensor.

3 Preset brightness levels.

Control other CYNC bulbs in the room with your switch.

Dim switch to desired level, then turn off. Use **Dim** button instead of center on/off button to turn on lights at the preset level.

Go to **CYNC** app and set the

Go to **CYNC app.** Add bulbs and switches to a room under **create a** 

Froom. (sold separately)

GE and C by GE are trademarks of General Electric Company. Used under trademark license.

PK-00100024-3

Connect to your Alexa or Hey Google device to control your lights with your voice.

Try these voice commands:

Amazon Alexa

Alexa, turn off the living room.

Alexa, good morning. Alexa, set kitchen

to 50%. **Hev Google** 

Hey Google, turn on the lights.

Hey Google, set bedroom to 20%. Hey Google, I'm leaving.

## Touch Controls & Sensors

power to the

sockets)

