

Like your new CYNC **Smart Sensor?** Share your experience!

Leave a review where you



PK-00102099-4

FCC ID: PUU-CWLMSONNWW1 IC: 10798A-CWLMSONNWW1

Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no augrantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected, or consult the dealer or an experienced radio/TV technician for help. This device complies with CAN ICES-3(B)/NMB-3(B)

Suitable for Damp locations. This device complies with

RF Exposure Information: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not

be less than 8 inches during normal operation. RF Exposure Statement: This equipment complies with ISED RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must be installed to provide a separation distance of at least 8 inches from all persons and must not be collocated or operating in conjunction with any other antenna or

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device

FCC Supplier's Declaration of Conformity Model: CWLMSONNWW1 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.GE Lighting,1975 Noble Road, Cleveland, OH, www.cbyge.com

Cet équipementest conforme aux limites d'expositionaux rayonnements de la ISED établiespour un environnement non contrôé. Cet équipement doit être insta**ll**é et fonctionner à au moins 20 cm dedistance d'un radiateur ou de votrecorps

L'émetteur/récepteur exempt de licencecontenu dans le présentappareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditionssuivantes :

- 1. L'appareil ne doit pasproduire de brouillage;
- 2. L'appareil doit acceptertout brouillage radioélectriquesubi, même si le brouillage estsusceptible d'en compromettre lefonctionnement.





Wire-Free Smart Motion Sensor Installation Guide

GE and C by GE are trademarks of General Electric Company. Used under trademark license.

Installing Smart Sensor

Recommended Tools

Phillips Screwdriver, Drill w/ 7/32 bit. Tape Measure

Screw Mount

- 1. Before installing, remove plastic battery tab.
- 2. Identify where you want to mount vour Smart Sensor (recommend placing between 66-78" from the
- 3. Mark the location for hole to be drilled
- 4. Using 7/32" bit, drill hole in wall for mounting screw, insert anchor.
- **5.** Remove magnetic mount from bracket, screw the bracket into the wall until flush, then replace magnetic mount in the bracket.
- 6. Mount Smart Sensor at desired
- 7. Smart Sensor can either be placed vertically or horizontally with the use

of the included magnetic mount. Freestandina

- 1. Identify where you want to place vour Smart Sensor. Any level shelf or surface is an ideal location for
- your sensor. 2. Install Smart Sensor and rotate to ideal anale.

Smart Sensor Set Up

Download the CYNC app.



Press Wake Button on the side of Smart Sensor to initiate setup *LED indicator light will flash blue until app set up is complete.



. Add your Smart Sensor to



Group your Smart Sensor in the same Room/Space in the CYNC app as the Smart Lights, Plugs, and Switches you want to motion control motion control.

Now you are all set to start making

automations and scenes with motion sensing


Tip: Set Up Scenes and Automations Before setting up scenes or automations in the CYNC app for your Smart Sensor. you will need to Wake Up the device by pressing the Wake Button on the side of the sensor.



Discover What Your Wire-Free

Smart Sensor Can Do:

Go to **CYNC app.** Add Wire-Free Smart Sensor and Smart Switch to a room under settinas. Enable motion sensor under device **settings.** (switch sold separately)



Go to **CYNC app.** Add Wire-Free Smart Sensor and Smart Light to a room under settinas. Enable motion sensor under device settings. (lights sold separately)



vou arrive home.


Go to **CYNC app.** Add Wire-Free Smart Sensor and Smart Plua to a room under settings. Enable motion sensor under device **settings.** (plug sold separately)

- 1. Remove Smart Sensor from mounting bracket.
- 2. Using Philips screwdriver remove screw from the back cover.

Battery Replacement

- 3. Slide the back cover up then outward to remove rear housing of the Smart Sensor.
- 4. Remove old batteries.
- 5. Install two new AAA batteries inside the bracket.
- 6. Replace back cover
- 7. Replace Smart Sensor.

Access battery



from back of Smart Sensor

For set up help, visit gelighting.com/cync